






ZB Sensor-Sealing Kit

(for units with high humidity and cooling mode)





separate the single stripes at the perforated mark (no tool necessary)



hold the stripe between the sensors



until it is completely covered



after 24h the material has created a shining layer



loose the paper from one side



and twist it around the sensor



close all gaps and tight it up



You have to do it with each of the sensors. The material will stay flexible and can easily and restless be removed.

